

# Maintenance Schedule

Service at the interval listed x 1,000 km (or miles) or after that number of months, whichever comes first.	R—Replace C—Clean		I—Inspect. After inspection, clean, adjust, repair or replace if necessary.				
	x 1,000 km x 1,000 miles months	20 12 12	40 24 24	60 36 36	80 48 48	100 60 60	
Idle speed and idle CO*3		I	I	I	I	I	
Idle speed and idle CO*4							I
Valve clearance		I	I	I	I	I	
Alternator drive belt			I		I		
Timing belt and timing balancer belt							R
Water pump							I
■ Engine oil and oil filter		Replace every 10,000 km (6,000 miles) or 6 months					
■ Transmission oil			R		R		
■ Radiator coolant					R*1		
Cooling system hoses and connections			I		I		
E.G.R. system (Standard for some types)							I
Secondary air supply system (Standard for some types)							I
Air cleaner element (Viscous type for European and KQ models)			R		R		
Air cleaner element (Dry type except European and KQ models)		R	R	R	R	R	
Fuel filter (Including aux filter*5)			R		R		
Tank, fuel line and connections			I		I		
Intake air temp. control system*3, *5							I
Throttle control system*3, *5			I		I		
Throttle control system*4, *5							I
Choke mechanism*5 (except KS models)			I		I		
Choke mechanism*5 (KS model)				C*7			I
Choke opener operation (only for carburetor automatic choke type)							I
Evaporative emission control system*6							I
Ignition timing and control system*3			I		I		
Ignition timing and control system*4							I
Spark plugs (for cars using unleaded gasoline)			R*2		R*2		
Spark plugs (for cars using leaded gasoline)		R	R	R	R	R	
Distributor cap and rotor*3			I		I		
Distributor cap and rotor*4							I
Ignition wiring*3			I		I		
Ignition wiring*4							I
Positive crankcase ventilation valve*3			I		I		
Positive crankcase ventilation valve*4							I
Blow-by filter*5			I		I		

■: These service intervals assume routine checking and replenishment has been done, as needed, by the customer.

\*1 Thereafter, replace every 2 years or 40,000 km (24,000 miles), whichever comes first.

\*2 For KS type, replace every 2 years or 40,000 km (24,000 miles) whichever comes first after 30,000 km (18,000 miles).

\*3 Except KS, KX models

\*4 KS, KX models

\*5 Only for carbureted type

\*6 Except KP, KT and 2.0 i of KE, KF

\*7 Recommended by manufacturer only



Service at the interval listed x 1,000 km (or miles) or after that number of months, whichever comes first.		R—Replace		I—Inspect. After inspection, clean, adjust, repair or replace if necessary.				
ITEM	x 1,000 km x 1,000 miles months	20	40	60	80	100		
		12	24	36	48	60		
Brake hoses and lines (Including anti-lock brake system hoses and pipes for anti-lock brake system models)		I	I	I	I	I		
Brake fluid (Including anti-lock brake system Fluid for anti-lock brake system models)			R		R			
Front brake discs and calipers		I	I	I	I	I		
Front brake pads		Inspect every 10,000 km (6,000 miles) or 6 months						
Rear brake discs, calipers and pads (for disk brake type)			I		I			
Rear brake drums, wheel cylinders and linings (for drum brake type)			I		I			
Parking brake		I	I		I			
Exhaust pipe and muffler		I	I	I	I	I		
Suspension mounting bolts		I	I	I	I	I		
Front wheel alignment (except 4WS models)		I	I	I	I	I		
Front and rear wheel alignment (4WS models)		I	I	I	I	I		
Steering operation, tie rod ends, steering gear box and boots (Including center shaft for 4WS models)	Except 4WS models	I	I		I			
	4WS models	I	I	I	I	I		
Anti-lock brake system high pressure hose (for anti-lock brake system models)					R			
Anti-lock brake system operation (for Anti-lock brake system models)		I	I		I			
Power steering system		I	I	I	I	I		
Power steering pump belt			I		I			
Catalytic converter heat shield (Standard for some types)						I		

**CAUTION:** The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

Severe driving conditions include:

A : Repeated short distance driving

B : Driving in dusty conditions

C : Driving in severe cold weather

D : Driving in areas using road salt or other corrosive materials

E : Driving on rough and/or muddy roads

F : Towing a trailer

R—Replace.

I— Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A B . . . F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
. . . . . F	Transmission oil	R	Every 20,000 km (12,000 miles) or 12 months
A B . D E F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A B . D E F	Rear brake discs, calipers and pads	I	Every 20,000 km (12,000 miles) or 12 months
. B C . E .	Power steering system	I	Every 10,000 km (6,000 miles) or 6 months

**CAUTION:** Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.