

Symbol Marks

The following symbols stand for:

 :Apply engine oil.

 :Apply brake fluid.

 :Apply grease.

 :Apply Automatic Transmission Fluid.

 : Apply Power Steering Fluid.

 :Apply or check vacuum.

①, ②, ③, :Sequence for removal or installation.
 ①, ②, ③, :Sequence for removal or installation.

Abbreviation

A/C	Air Conditioner
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
B or BAT	Battery
CATA	Catalytic Converter
EACV	Electronic Air Control Valve
ECU	PGM-FI Electronic Control Unit
EGR	Exhaust Gas Recirculation
EX	Exhaust
GND	Ground
IG	Ignition
IN	Intake
INT	Intermittent
L	Left
LHD	Left Hand Drive
M/T	Manual Transmission
RCV	Poaitive Crankcase Ventilation
PGM-FI	Programmed Fuel-Injection
P/S	Power Steering
R	Right
RHD	Right Hand Drive
SW	Switch
SOL. V	Solenoid Valve
TDC	Top Dead Center

P	Parking
R	Reverse
N	Neutral
D₄	Drive Position (1st~4th)
D₃	Drive Position (1st~3rd)
2	Fixed 2nd speed
1	Fixed 1st speed
S	S signal/S Switch