


# Interlock System (KQ model)

## Component Location Index





## Description



The car is equipped with the following devices to prevent inadvertent shifting:

- A/T selector with shift lock
- Key cylinder with interlocked ignition key

### Shift Lock System:

The shift lock system prevents the shift lever from moving to **R** or **D** from the **P** position unless you step on the brake pedal.


NOTE: In case of system malfunction, the shift lever can be released by pushing a key into the release slot near the shift lever.




### Key Interlock System:

The ignition key cannot be removed from the ignition switch unless the shift lever is in the **P** position.


If the key is inserted when the shift lever is in any position other than **P**, a solenoid is activated, making it impossible for the key to be removed until the shift lever is moved to the **P** position.



The shift lever is in the **P** position:




The shift lever is in any position except **P**:



# Interlock System (KQ model)

## Circuit Diagram

NOTE: Different wires with the same color have been given a number suffix to distinguish them (for example, GRN/WHT<sup>1</sup> and GRN/WHT<sup>2</sup> are not the same.)






## Interlock Control Unit Input Test

Disconnect the 14-P connector from the control unit. Inspect the connector terminals to be sure they are all making good contact.

- If the terminals are bent, loose or corroded, repair them as necessary, and recheck the system.
- If the terminals look OK, make the following input tests at the connector.
  - If any test indicates a problem, find and correct the cause, then recheck the system.
  - If all the input tests prove OK, the control unit must be faulty; replace it.

NOTE: If the shift lock solenoid clicks when the ignition switch ON and the brake pedal is pushed (the shift lever is in the **P** position), the shift lock system is electronically normal. If the shift lever can not be shifted from **P** position, see A/T system.



### Shift Lock System:

No.	Wire	Test condition	Test: Desired result	Possible cause if result is not obtained
1	GRN/WHT <sup>1</sup>	Ignition switch ON. Brake pedal pushed.	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 25 (20 A) fuse.</li> <li>• Faulty brake light switch.</li> <li>• An open in the wire.</li> </ul>
2	GRN/WHT <sup>2</sup>	Shift lever in position <b>P</b> .	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Faulty shift position console switch.</li> <li>• Poor ground (G401, G402)</li> <li>• An open in the wire.</li> </ul>
3	GRN	Ignition switch ON.	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 1 (10 A) fuse.</li> <li>• Faulty shift lock solenoid.</li> <li>• An open in the wire.</li> </ul>


### Key Interlock System:

No.	Wire	Test condition	Test: Desired result	Possible cause if result is not obtained
1	BLK	Under all conditions.	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G401, G402).</li> <li>• An open in the wire.</li> </ul>
2	GRN/WHT <sup>2</sup>	Shift lever in position <b>P</b> .	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Faulty shift position console switch.</li> <li>• Poor ground (G401, G402).</li> <li>• An open in the wire.</li> </ul>
3	WHT/RED	Ignition switch turned to ACC (I) and the key pushed in.	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 25 (20 A) fuse.</li> <li>• Faulty steering lock assembly (key interlock solenoid).</li> <li>• An open in the wire.</li> </ul>
	WHT/BLU			

# Interlock System (KQ model)

## Key Interlock Solenoid Test

1. Remove the dashboard lower cover.
2. Disconnect the 6-P connector from the main wire harness.




3. Check for continuity between the terminals in each switch position according to the table.

		Terminal		
		A	B	C
Ignition switch ACC (I)	Key pushed in.	○ — ○	○ — ○	○ — ○
	Key released.		○ — ○	

4. Check that the key cannot be removed with power and ground connected to the A and C terminals.

- If the key cannot be removed, the key interlock solenoid is OK.
- If the key can be removed, replace the steering lock assembly (the key interlock solenoid is not available separately).



# Shift Lock Solenoid Test/Replacement

### Test:


1. Remove the console, then disconnect the 3-P connector of the shift lock solenoid from the main wire harness.

NOTE: This solenoid has a diode in it. To get an accurate reading, either test it with a volt-ohmmeter that compensates for diodes, or make sure you connect your test leads to match the polarity shown.

2. Connect battery power to the A terminal and ground to the B terminal momentarily. Check the solenoid. If it does not work, replace it.

### NOTE:

- When the shift lock solenoid is ON, check that there is a clearance of  $2.5 \pm 0.5 \text{ mm}$  ( $0.098 \pm 0.020 \text{ in}$ ) between the top of the shift lock lever and the lock pin groove (see clearance check on this page).
- When the shift lock solenoid is OFF, make sure that the lock pin is blocked by the shift lock lever.
- If it is not blocked, adjust the position of the shift lock solenoid.




### Replacement:

1. Remove the solenoid pin.
2. Remove the self-locking nuts and shift lock solenoid.


### SELF-LOCKING NUTS

Replace.  
10 N·m  
(1.0 kg-m, 7.2 lb-ft)



3. Install the shift lock solenoid in the reverse order of removal and adjust its position.
  - When the shift lock solenoid is ON, check that there is a clearance of  $2.5 \pm 0.5 \text{ mm}$  ( $0.098 \pm 0.020 \text{ in}$ ) between the top of the shift lock lever and the lock pin groove, and tighten the self-locking nuts.

NOTE: Use brand-new self-locking nuts.



- When the shift lock solenoid is OFF, make sure that the lock pin is blocked by the shift lock lever.

NOTE: Test the solenoid after you assemble it.

