

Required Maintenance Schedule

SERVICE AT THE INTERVAL OF LISTED KM (MILES) OR MONTHS, WHICHEVER OCCURS FIRST.						
ITEMS	x 1,000 km	20	40	60	80	100
	x 1,000 miles	12	24	36	48	60
	months	12	24	36	48	60
IDLE SPEED AND IDLE CO	I	I	I	I	I	I
VALVE CLEARANCE	I	I	I	I	I	I
ALTERNATOR DRIVE BELT	I	I	I	I	I	I
ENGINE OIL AND OIL FILTER	Replace every 10,000 km (6,000 miles) or 6 months					
TRANSMISSION OIL			R		R	
RADIATOR COOLANT					R*1	
COOLING SYSTEM HOSES AND CONNECTIONS		I		I		
SECONDARY AIR SUPPLY SYSTEM*2						I
AIR CLEANER ELEMENT	R*2	R	R*2	R		R*2
FUEL FILTER		R		R		
INTAKE AIR TEMP. CONTROL SYSTEM*2						I
TANK, FUEL LINE AND CONNECTIONS		I		I		
THROTTLE CONTROL SYSTEM*2		I		I		
CHOKE MECHANISM*2		I		I		
EVAPORATIVE EMISSION CONTROL SYSTEM						I
IGNITION TIMING AND CONTROL SYSTEM		I		I		
SPARK PLUGS (For cars using leaded gasoline)	R	R	R	R	R	R
SPARK PLUGS (For cars using unleaded gasoline)		R		R		
DISTRIBUTOR CAP AND ROTOR		I		I		
IGNITION WIRING		I		I		
CRANKCASE EMISSION CONTROL SYSTEM		I		I		
BRAKE HOSES, LINES	I	I	I	I	I	I
BRAKE FLUID		R		R		
FRONT BRAKE DISCS AND CALIPERS	I	I	I	I	I	I
FRONT BRAKE PADS	Inspect every 10,000 km (6,000 miles) or 6 months					
REAR BRAKES	I	I	I	I	I	I
PARKING BRAKE	I	I	I	I	I	I
CLUTCH RELEASE ARM TRAVEL	I	I	I	I	I	I
ENGINE EXHAUST SILENCER, SUSPENSION MOUNTING BOLTS	I	I	I	I	I	I
FRONT WHEEL ALIGNMENT	I	I	I	I	I	I
STEERING OPERATION, TIE ROD ENDS, STEERING GEAR BOX AND BOOTS	I	I	I	I	I	I
CATALYTIC CONVERTER HEAT SHIELD						I

R—Replace

I—Inspect. After inspection, clean, adjust, repair or replace if necessary

■ REMARK: Day to day care (such as oil, coolant check and replenishment) should be done practically according to the Owner's Manual.

*1 Thereafter, replace every 2 years or 48,000 km (30,000 miles), whichever comes first.

*2 KY type only.

CAUTION: The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

"Severe driving conditions" include:

- A: Repeated short-distance driving
- B: Driving in dusty conditions
- C: Driving in severe, cold weather
- D: Driving in areas using road salt or other corrosive materials
- E: Driving on rough and/or muddy roads
- F: Towing a trailer

R—Replace

I—Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A, B, F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
A, B, D, E, F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A, B, C, E, F	Clutch release arm travel	I	Every 10,000 km (6,000 miles) or 6 months