



12. Suspension

Number	Tool Number	Description	Q'ty	Remarks
①	07GAE-SE00100	Spring Compressor	1	
②	07GAF-SE00200	Hub Assembly Guide Attachment	1	
③	07GAF-SE00401	Hub Dis/Assembly Base	1	
④	07HGK-0010100	Wheel Alignment Gauge Attachment	1	
⑤	07JAF-SH20110	Hub Dis/Assembly Pilot, 38mm	1	
⑥	07JAF-SH20120	Hub Dis/Assembly Shaft, 22.4×25.4mm	1	
⑦	07JAF-SH20200	Ball Joint Remover Base	1	
⑧	07746-0010400	Attachment, 52×55mm	1	
⑨	07746-0010600	Attachment, 72×75mm	1	
⑩	07749-0010000	Driver	1	
⑪	07941-6920003	Ball Joint Remover	1	
⑫	07965-SB00100	Ball Joint Remover/Installer	1	
⑬	07965-SB00200	Ball Joint Installer Base	1	
⑭	07965-6340301	Hub Dis/Assembly Base	1	
⑮	07965-6920201	Hub Dis/Assembly Base	1	
⑯	07974-SA50700	Ball Joint Boot Clip Guide A	1	
⑰	07974-SA50800	Ball Joint Boot Clip Guide B	1	

13. Brakes

Number	Tool Number	Description	Q'ty	Remarks
①	07GAG-SE00100	Pushrod Adjustment Gauge	1	
②	07HAE-SG00100	Brake Spring Compressor	1	
③	07404-5790300	Vacuum Gauge	1	
④	07406-5790200	Oil Pressure Gauge	2	
⑤	07410-5790100	Pressure Gauge Attachment C	2	
⑥	07410-5790500	Tube Joint Adaptor	1	
⑦	07510-6340101	Pressure Gauge Joint Pipe	2	
⑧	07510-6340300	Vacuum Joint Tube A	1	
⑨	07749-0010000	Driver	1	
⑩	07914-SA50001	Snap Ring Pliers	1	07949-6110000 may also be used.
⑪	07921-0010001	Flare Nut Wrench	1	
⑫	07947-6890300	Driver Attachment C	1	

15. Heater and Air Conditioner

Number	Tool Number	Description	Q'ty	Remarks
①	07HAF-SF10300	Seal Seat Remover	1	Cover plate removal
②	07HAF-SF10400	Seal Remover/Installer	1	Shaft seal removal/installation
③	07746-0030100	Driver C	1	Pulley installation

16. Electrical

Number	Tool Number	Description	Q'ty	Remarks
①	07920-SB20000	Fuel Sender Wrench	1	