

Radiator

Illustrated Index

SOHC Carbureted Engine :

⚠ WARNING System is under high pressure when engine is not. To avoid danger of releasing scalding coolant, remove cap only when engine is cool.

CAUTION : When supplying coolant, be sure to shut the relay box lid and not to let coolant spill on the electrical parts or the painted portion. If any coolant spills, rinse it off immediately.

Total Cooling System Capacity (Incl. heater, and reservoir 0.4 liters) :

M/T : 5.4ℓ (5.7 US qt, 4.8 Imp qt)

A/T : 5.3ℓ (5.6 US qt, 4.7 Imp qt)

NOTE:

- Check all cooling system hoses for damage, leaks or deterioration and replace if necessary.
- Check all hose clamps and retighten if necessary.
- Use new O-rings whenever reassembling.

RADIATOR

Inspect seams between core fins and tanks for leaks.

Blow dirt out from between core fins with compressed air. If insects, etc., are clogging radiator, wash them off with low pressure water.

