



## 8 . Manual Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAJ-PG20102	Mainshaft Clearance Inspection Tool Set	1	
①-1	07GAJ-PG20110	Mainshaft Holder	1	
①-2	07GAJ-PG20120	Collar	1	
①-3	07GAJ-PG20130	Mainshaft Base	1	
②	07744-0010200	Pin Driver 3 mm	1	
③	07744-0010400	Pin Driver , 5 mm	1	
④	07746-0010300	Attachment , 42×47 mm	1	
⑤	07746-0010401	Attachment , 52×55 mm	1	
⑥	07746-0030100	Driver	1	
⑦	07746-0030400	Driver , 35 mm	1	
⑧	07749-0010000	Driver	1	
⑨	07936-6340000	Bearing	1	
⑩	07944-SA00000	Pin Driver , 4 mm	1	
⑪	07947-6110500	Oil Seal Driver	1	
⑫	07947-6340500	Oil Seal Driver Attachment E	1	
⑬	07948-SC20200	Oil Seal Driver	1	
⑭	07979-PJ40001	Magnet Stand Base	1	

## 9 . Automatic Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAC-PF040210	Bearing Remover Attachment	1	Use in place of 07936-634000 attachment
②	07GAE-PG40001	Clutch Spring Compressor Set	1	
②-1	07GAE-PG40200	Compressor Bolt Assembly	(1)	} -Component tools
②-2	07HAE-PG40200	Compressor Attachment	(1)	
②-3	07960-6120100	Compressor Attachment	(1)	
③	07HAC-PK40100	Transmignon Housing Puller	1	
④	07HAD-SF10100	Attachment	1	
⑤	07JAD-PH80400	Pilot Driver 28×30 mm	1	
⑥	07406-0020003	Oil Pressure Gauge Set	1	
⑥-1	07406-0020201	Oil Pressure Gauge Hose Attachment	(1)	Component tool
⑦	07406-0070000	Low Pressure Gauge	1	
⑧	07746-0010500	Attachment , 62×68 mm	1	07947-6340400 may also be used .
⑨	07746-0030100	Inner Handle C	1	
⑩	07749-0010000	Driver	1	07949-6110000 may also be used .
⑪	07923-6890202	Mainshaft Holder	1	
⑫	07936-6340000	Bearing Remover Set	1	
⑬	07944-SA00000	Pin Driver , 4.0 mm	1	
⑭	07947-6110501	Driver Attachment E	1	
⑮	07947-6340201	Oil Seal Driver	1	
⑯	07947-6340500	Driver Attachment E	1	
⑰	07948-SC20200	Oil Seal Driver	1	