

Symbol Marks

The following symbols stand for:



:Apply engine oil.



:Apply brake fluid.



:Apply grease.



:Apply Automatic Transmission Fluid



: Apply Power Steering Fluid.



:Apply or check vacuum.

①, ②, ③, : Sequence for removal or installation
 ①, ②, ③, : Sequence for removal or installation

Abbreviation

A/C	Air Conditioner
ALB Assy	4-channel Anti Lock Brake Assembly
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
ATT	Attachment
B or BAT	Battery
CATA	Catalytic Converter
EACV	Electronic Air Control Valve
ECU	PGM-FI Electronic Control Unit
EGR	Exhaust Gas Recirculation
EX	Exhaust
GND	Ground
IG	Ignition
IN	Intake
INT	Intermittent
L.	Left
LHD	Left Hand Drive
M/T	Manual Transmission
PCV	Positive Crankcase Ventilation
PGM-FI	Programmed Fuel-Injection
P/S	Power Steering
R.	Right
RHD	Right Hand Drive
SW	Switch
SOL. V	Solenoid Valve
TDC	Top Dead Center
P	Parking
R	Reverse
N	Neutral
D₁	Drive Position (1st-4th)
D₂	Drive Position (1st-3rd)
2	2nd Position