

Maintenance Schedule

Service at the interval listed x 1,000 km (or miles) or after that number of months, whichever comes first.	R—Replace C—Clean		I—Inspect. After inspection, clean, adjust, repair or replace if necessary.			
	x 1,000 km x 1,000 miles months	20 12 12	40 24 24	60 36 36	80 48 48	100 60 60
Idle speed and idle CO*3		I	I	I	I	I
Idle speed and idle CO*4						I
Valve clearance		I	I	I	I	I
Alternator drive belt			I		I	
Timing belt						R
Water pump						I
■ Engine oil and oil filter		Replace every 10,000 km (6,000 miles) or 6 months				
■ Transmission oil			R		R	
■ Radiator coolant					R*1	
Cooling system hoses and connections			I		I	
Air cleaner element (Viscous type for European and KQ models)			R		R	
Air cleaner element (Dry type except European and KQ models)		R	R	R	R	R
Fuel filter			R		R	
Tank, fuel line and connections			I		I	
Intake air temp. control system*5						I
Throttle control system*5			I		I	
Choke mechanism*5			I		I	
Choke mechanism*6				C*7		I
Evaporative emission control system (for cars using unleaded gasoline and KY model)						I
Ignition timing and control system*3			I		I	
Ignition timing and control system*4						I
Spark plugs (for cars using unleaded gasoline)			R*2		R*2	
Spark plugs (for cars using leaded gasoline)		R	R	R	R	R
Distributor cap and rotor*3			I		I	
Distributor cap and rotor*4						I
Ignition wiring*3			I		I	
Ignition wiring*4						I
Positive crankcase ventilation valve*3			I		I	
Positive crankcase ventilation valve*4						I
Blow-by filter*5			I		I	

■: These service intervals assume routine checking and replenishment has been done, as needed, by the customer.

*1 Thereafter, replace every 2 years or 40,000 km (24,000 miles), whichever comes first.

*2 For KS type, replace every 2 years or 40,000 km (24,000 miles) whichever comes first after 30,000 km (18,000 miles).

*3 Except KS, KX models

*4 KS, KX models

*5 Only for carbureted types (except KS model)

*6 Only for carbureted type (KS model)

*7 Recommended by manufacturer only



Service at the interval listed x 1,000 km (or miles) or after that number of months, whichever comes first.	R—Replace		I—Inspect. After inspection, clean, adjust, repair or replace if necessary.			
	x 1,000 km x 1,000 miles months	20 12 12	40 24 24	60 36 36	80 48 48	100 60 60
Brake hoses and lines (Including ALB hoses and pipes for ALB models)		I	I	I	I	I
Brake fluid (Including ALB fluid for ALB models)			R		R	
Front brake discs and calipers		I	I	I	I	I
Front brake pads		Inspect every 10,000 km (6,000 miles) or 6 months				
Rear brake discs, calipers and pads (for rear disk brake type)			I		I	
Rear brake drums, wheel cylinders and linings (for rear drum brake type)			I		I	
Parking brake		I	I		I	
Clutch release arm travel		I	I	I	I	I
Exhaust pipe and muffler		I	I	I	I	I
Suspension mounting bolts		I	I	I	I	I
Front wheel alignment		I	I	I	I	I
Steering operation, tie rod ends, steering gear box and boots		I	I		I	
ALB high pressure hose (for ALB models)					R	
ALB operation (for ALB models)		I	I		I	
Power steering system (Standard for some types)		I	I	I	I	I
Power steering pump belt (Standard for some types)			I		I	
Catalytic converter heat shield (Standard for some types)					I	

CAUTION: The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

Severe driving conditions include :

A : Repeated short distance driving

B : Driving in dusty conditions

C : Driving in severe cold weather

D : Driving in areas using road salt or other corrosive materials

E : Driving on rough and/or muddy roads

F : Towing a trailer

R—Replace.

I— Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A B . . . F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
. F	Transmission oil	R	Every 20,000 km (12,000 miles) or 12 months
A B . D E F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A B . D E F	Rear brake discs, calipers and pads	I	Every 20,000 km (12,000 miles) or 12 months
A B C . E F	Clutch release arm travel	I	Every 10,000 km (6,000 miles) or 6 months
. B C . E .	Power steering system	I	Every 10,000 km (6,000 miles) or 6 months

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.