



## Description

### Fan Timer System:

When the air temperature of engine room is above approx. 60°C (140°F) after the engine is stopped, the condenser fan goes into operation to cool the engine for a maximum of 10 minutes.

When the temperature falls below 42°C (108°F), the fan is stopped.

The TA switch is located on the control box bracket (carbureted engine) or firewall (fuel-injected engine) and the fan timer unit is located right side under dash.

	Ignition Switch					
	ON		ON → OFF		ON	
	Coolant Temp. Switch A		Air Temp. (TA) switch		A/C System	
	Above 90°C (194°F)	Below 83°C (181°F)	Above 60°C (140°F)	Below 42°C (108°F)	ON	OFF
Radiator Fan	ON	OFF	ON (10 min)	OFF	ON	OFF
Condenser Fan	ON	OFF	OFF	OFF	ON	OFF