

Wiring Diagrams

Index

Air Conditioner System	14	PGM—CARB Control System	13
ALB System	7	PGM—FI Control System	12
A/T Control System	13	Power Door Lock System	10
Battery	1	Power Door Mirror System	9
Carburetor Solenoids (Except KS,KX,KZ)	12	Power Window System	10
Charging System	1	Rear Window Defogger System	9
Cigarette Lighter	9	Rear Window Wiper/Washer System	10
Clock	9	Safety Indicator	2
Cooling System	2	Seat Heater System	11
Cruise Control System	11	Shift Lever Position Indicator	3
Dashlight Brightness Control Unit	7	Starting System	1
Fuel Pump Carbureted Engine	13	Stereo Sound System	8
Fuel Injected Engine	12	Sunroof System	9
Gauges	2	Warning Lights	
Headlight Washer System	11	ALB Warning	7
Heater Control System	14	Brake Warning	2
Ignition Switch	1	Charge Warning	1
Ignition System	1	Compressor Warning	14
Indicator Lights		Low Fuel Warning	2
Air Conditioner	12	Oil Pressure Warning	3
Cruise Control Main Switch	11	PGM—FI Warning	12
Hazard Light(Except KQ,KT,KY)	8	Seat Belt Reminder	4
Rear Defogger	9	Windshield Wiper/Washer System	10
Rear Fog Light KE	4		
KS,KW,KQ,KT,KY	5		
KB,KF,KG,KX	6		
S4 Switch	13		
Seat Heater	11		
Instrument Panel Light	3		
Integrated Control Unit	3		
Lighting System KB,KF,KG,KX	6		
KE	4		
KS,KW,KQ,KT,KY	5		
Lights			
Brake Light	8		
Dome Light	2		
Door Key Light	3		
Fuse Box Light	8		
Fog Lights KE	4		
KB,KF,KG,KX	6		
KS,KW,KQ,KT,KY	7		
Gauge Light	2		
Grove Box Light	8		
Headlight KB,KF,KG,KX	6		
KE	4		
KS,KW,KQ,KT,KY	5		
Ignition Key Light	3		
Safety Indicator Light	2		
Trunk Light	2		
Turnsignal Light	8		