

Special Tools

10. Driveshaft

Number	Tool Number	Description	Q'ty	Remarks
①	07GAD-SE00100	Oil Seal Driver Attachment	1	
②	07746-0010400	Attachment, 52 x 55 mm	1	
③	07746-0010500	Attachment, 62 x 68 mm	1	
④	07746-0040900	Pilot, 40 mm	1	
⑤	07749-0010000	Driver	1	
⑥	07947-SD90200	Oil Seal Driver	1	
⑦	07965-SD90100	Support Base	1	
⑧	07965-SD90200	Support Collar	1	

11. Power Steering (2WS/4WS Community)

Number	Tool Number	Description	Q'ty	Remarks
①	07GAG-SD40000	P/S Tool Kit	1	
①-1	07GAG-SD40100	Piston Seal Ring Guide	(1)	Component tools
①-2	07GAG-SD40200	Piston Seal Sizing Tool	(1)	
①-3	07GAG-SD40300	Cylinder End Seal Slider	(1)	
①-4	07GAG-SD40400	End Seal Guide	(1)	
①-5	07GAG-SD40600	Tool Box	(1)	
②	07GAK-SE00100	P/S Pressure Gauge Adaptor Set	1	
②-1	07GAK-SE00110	P/S Joint Adaptor (Pump)	(1)	Component tools
②-2	07GAK-SE00120	P/S Joint Adaptor (Hose)	(1)	
③	07406-0010101	Bypass Tube Joint	1	
④	07406-0010200	P/S Pressure Gauge Set	1	
④-1	07406-0010300	Pressure Control Valve	(1)	Component tools
④-2	07406-0010400	Pressure Gauge	(1)	
⑤	07725-0030000	Pulley Holder	1	
⑥	07746-0010300	Attachment, 42 x 47 mm	1	
⑦	07749-0010000	Driver	1	
⑧	07916-SA50001	40 mm Lock Nut Wrench	1	
⑨	07941-6920003	Ball Joint Remover	1	
⑩	07947-6340300	Driver Attachment	1	
⑪	07953-7190000	Collar Driver	1	
⑫	07974-SA50600	Pinion Seal Guide	1	



11. Power Steering (4WS only)

Number	Tool Number	Description	Q'ty	Remarks
①	07HAA-SF10100	Lock Nut Socket 36 x 41 mm	1	
②	07HAG-SF10000	4WS Tool Kit	1	
②-1	07HAG-SF10100	Piston Seal Ring Guide	(1)	Component tools
②-2	07HAG-SF10200	Piston Seal Ring Sizing Tool	(1)	
②-3	07HAG-SF10300	Pinion Seal Ring Guide	(1)	
②-4	07HAG-SF10400	Pinion Seal Sizing Tool	(1)	
②-5	07HAG-SF10500	Driver Seal Ring Guide	(1)	
②-6	07HAG-SF10600	Tool Box	(1)	
③	07HAJ-SF10100	Rack Adjuster Gauge Holder Set	1	
④	07HAJ-SF10201	Rear Adjuster Center Lock Pin	1	
⑤	07HAJ-SF10300	Stroke Rod Holder Set	1	
⑥	07HAJ-SF10400	Inspection Adaptor	1	
⑦	07703-0010101	Torx Driver Bit T40	1	
⑧	07746-0010700	Attachment 24 x 26 mm	1	

12. Suspension

Number	Tool Number	Description	Q'ty	Remarks
①	07GAE-SE00101	Spring Compressor	1	may also be used 07GAE-SE00100
②	07GAF-SD40700	Hub Dis/Assembly Base	2	
③	07GAF-SE00100	Hub Assembly Pin	1	
④	07GAF-SE00200	Front Assebmly Driver Attachment	1	
⑤	07GAF-SE00401	Front Hub Base	1	
⑥	07GAG-SD40700	Ball Joint Boot Clip Installation Guide	1	
⑦	07GAK-0010100	Wheel Alignment Gauge Attachment	1	
⑧	07HAD-SF10100	Hub Bearing Driver	1	
⑨	07HAF-SF10100	Ball Joint Dis/Assebmly Tool Kit	1	
⑨-1	07HAF-SF10110	Ball Joint Remover Base	(1)	Component tools
⑨-2	07HAF-SF10120	Ball Joint Installer Base	(1)	
⑨-3	07HAF-SF10130	Ball Joint Remover/Installer	(1)	
⑩	07HAF-SF10200	Bearing Supporting Attachment	1	
⑪	07HAJ-SF10201	Rear Steering Center Lock Pin	1	
⑫	07HGJ-0010000	Toe Inspection Gauge Set	1	
⑬	07703-0010100	Torx Driver Bit T40	1	
⑭	07746-0010400	Attachment, 52 x 55 mm	1	
⑮	07746-0010500	Attachment, 62 x 68 mm	1	
⑯	07749-0010000	Driver	1	
⑰	07941-6920003	Ball Joint Remover	1	
⑱	07965-SB00000	Ball Joint Dis/Assembly Tool Set	1	
⑱-1	07965-SB00100	Ball Joint Remover Base	(1)	Component tools
⑱-2	07965-SB00200	Ball Joint Installer Base	(1)	
⑱-3	07965-SB00300	Ball Joint Remover/Installer	(1)	
⑲	07965-SD90100	Supporting Base	1	
⑳	07965-6920201	Front Hub Dis/Assembly Tool, B	1	
㉑	07974-SA50700	Ball Joint Boot Clip Installation Guide	1	
㉒	07974-SA50800	Ball Joint Boot Clip Installation Guide	1	