

Symbol Marks

The following symbols stand for:



:Apply engine oil.



:Apply brake fluid.



:Apply grease.



: Apply DEXRON® or DEXRON® II Automatic Transmission Fluid.



: Apply Power Steering Fluid.



:Apply or check vacuum.

①, ②, ③ : Sequence for removal or installation
①, ②, ③ :

Abbreviation



2WS	Two Wheel Steering
4WS	For Wheel Sterring
A/C	Air Conditioner
ALB	Anti Lock Brake
Assy	Assembly
A/T	Automatic Transmission
ATF	DEXRON® or DEXRON® II Automatic Transmission Fluid
ATT	Attachment
EACV	Electronic Air Control Valve
ECU	Electronic Control Unit for Fuel-Injection System
EGR	Exhaust Gas Recirculation
GND	Ground
IG	Ignition
INT	Intermittent
L.	Left
LHD	Left Hand Drive
M/T	Manual Transmission
PCV Valve	Positive Crankcase Ventilation Valve
PGM-FI	Programmed Fuel Injection
PGM-CARB	Programmed Carburetor
P/S	Power Steering
R.	Right
RHD	Right Hand Drive
SW	Switch
SOL. V	Solenoid valve
TDC	Top Dead Center
P	Parking
R	Reverse
N	Neutral
D	Drive range
S	Sports range
2	Fixed at 2nd