



## 7. Clutch

Number	Tool Number	Description	Q'ty	Remarks
①	07GAG—PF50100	Clutch Disc Alignment Tool	1	
②	07924—PD20003	Ring Gear Holder	1	may also be used 07924—PD20002

## 8. Manual Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAD—PG40100	Oil Seal Driver	1	may also be used 07947—SD90100
②	07GAJ—PG20101	Preload Inspection Tool	1	
③	07746—0010300	Attachment, 42 x 47 mm	1	
④	07746—0010400	Attachment, 52 x 55 mm	1	
⑤	07746—0010500	Attachment, 62 x 68 mm	1	
⑥	07746—0030100	Driver	1	
⑦	07749—0010000	Driver	1	
⑧	07936—6340000	Bearing Puller Set	1	
⑨	07936—6890101	Bearing Remover Attachment	1	
⑩	07947—6110500	Oil Seal Driver	1	

## 9. Automatic Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAB—PF50100	Mainshaft Holder	1	
②	07GAC—PF40210	Bearing Remover Attachment	1	
③	07GAE—PG40001	Clutch Spring Compressor Set	1	
③-1	07GAE—PG40200	Clutch Spring Compressor Bolt Assembly	(1)	} Component tools
③-2	07HAE—PL50100	Clutch Spring Compressor Attachment	(1)	
③-3	07960—6120100	Clutch Spring Compressor Attachment	(1)	
④	07GAJ—PG20201	Preload Inspection Tool	1	
⑤	07GMJ—ML80100	Inspection Adaptor Tool	1	
⑥	07HAC—PK40100	Housing Puller	1	may also be used 07GAC—PG40100, 07GAC—PG40101, 07GAC—PG40102
⑦	07HAF—PK40100	Gear Installer	1	
⑧	07406—0020003	Oil Pressure Gauge Set	1	may also be used 07406—0020201
⑨	07746—0010500	Attachment, 62 x 68 mm	1	
⑩	07746—0030100	Driver	1	
⑪	07749—0010000	Driver	1	
⑫	07936—6340000	Bearing Puller Set	1	
⑬	07947—SD90100	Oil Seal Driver	1	may also be used 07GAD—PG40100
⑭	07947—6110500	Oil Seal Driver	1	
⑮	07947—6340201	Driver Attachment E	1	
⑯	07947—6340500	Bearing Driver Attachment E	1	