

1995-1998 2.5TL/3.2TL Body Repair Manual

Body Repair

INTRODUCTION

How to Use This Manual

This manual covers the repairs of 1995-1998 Acura 2.5TL/3.2TL automobiles which have been involved in accidents, and it describes the work related to the replacement of damaged body parts. Please read through these instructions and familiarize yourself with them before actually using this manual.

NOTE: Refer to the 1995-1998 Acura 2.5TL Service Manual (P/N 61SW504) and 1996-1998 Acura 3.2TL Service Manual Supplement (P/N 61SW505) for specifications, wire harness locations, safety stand support points, etc.

Special Information

WARNING

Indicates a strong possibility of severe personal injury or death if instructions are not followed.

CAUTION

Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE: Gives helpful information.

CAUTION

Detailed descriptions of standard workshop procedures, safety principles and service operations are not included. Please note that this manual does contain warnings and cautions against some specific service methods which could cause PERSONAL INJURY, damage a vehicle, or make it unsafe. Please understand that these warnings cannot cover all conceivable ways in which service, whether or not recommended by Honda, might be done or of the possible hazardous consequences of each conceivable way, nor could Honda investigate all such ways. Anyone using service procedures or tools, whether or not recommended by Honda, must satisfy himself thoroughly that neither personal safety or vehicle safety will be jeopardized.

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at any time without notice. No part of this publication may be reproduced, stored in retrieval system, or transmitted, in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. This includes text, figures and tables.

HONDA MOTOR CO., LTD.
Service Publication Office

1 Preparation of Work

2 Welding Methods/Repair Tools

3 General Information

4 Replacement

5 Cross Section of Body and Sealants

6 Body Dimensional Drawings

7 Rust-preventive Treatments

Paint Repair

8 Body Paint Repair

9 Resin Parts Paint Repair (Exterior)

Service Precautions

General Safety Precautions