Component Locations

Index

[KX, KS, KZ model (4WS)]



[KF, KG, KW, KB model (4WS)]



[KE model (4WS)]


A/C IDLE BOOST SOLENOID VALVE
Troubleshooting, page 6-17
INNER VENT SOLENOID VALVE
IDLE BOOST SOLENOID VALVE
Troubleshooting, page 6-15
AIR BLEED VALVE A
THERMOVALVE
THERMOVALVE
AIR BLEED VALVE B
ANTI-AFTERBURN VALVE
THROTTLE CABLE