



Timing Belt

Illustrated Index

NOTE :

- Refer to page 5-21 for positioning crank and pulley before installing belt.
- Refer to page 5-7, for alternator belt adjustment.
- Refer to page 5-8, for A/C compressor belt adjustment.
- Refer to page 5-9, for P/S pump belt adjustment.
- Before removing, mark direction of rotation.

