

# Headlight Adjuster (KG model only)

## Circuit Diagram

### Discription :

The motor-driven type headlight adjuster is mounted behind the headlight unit. When you operate the adjuster switch, the motor driving circuit senses the ground through each resistor and the headlight adjuster is actuated.

