





Positioning Crankshaft Before Installing Timing Belt




NOTE:

- Install the timing belt with the No. 1 piston at TDC (Top Dead Center) on the compression stroke.
- If pulley bolt broke loose while turning crank, retorque it to 165 N·m (16.5 kg-m, 119 lb-ft).

except 1.6ℓ :



1.6ℓ :



NOTE:

- To set the crankshaft to TDC, install the timing belt guide plates, timing belt drive pulley, timing belt lower cover, crankshaft pulley, and crankshaft pulley bolt.