


Relays and Control Unit Locations

Engine Compartment






Door and Floor


NOTE:

- The illustration is L.H. drive type.
- R.H. drive type is symmetrical to L.H. drive type.

POWER DOOR LOCK
CONTROL UNIT




R. DOOR
INNER
PANEL




FRONT SEAT

SEAT HEATER
RELAY (KS, KW models)



A/T CONTROL UNIT



ECU COVER
(Located right
front floor)


Fuel-injected engine: PGM-FI ECU
Carbureted engine: PGM-CARB CONTROL UNIT

Relays and Control Unit Locations

Dashboard

NOTE:

- The illustration is L.H. drive type.
- R.H. drive type is symmetrical to L.H. type.





NOTE:

- The illustration is L.H. drive type.
- R.H. drive type is symmetrical to L.H. drive type.

