





Ground Distribution

Circuit Identification


NOTE: See pages 16-6 and 7 for illustrated ground locations.



L.H. Drive:



R.H. Drive:



A: Battery ground wire
B: Engine ground wire A
C: Engine ground wire B

D: Engine wire harness
E: Right engine compartment wire harness
F: Left engine compartment wire harness

G: Main wire harness


(cont'd)

Ground Distribution


Circuit Identification

NOTE: See pages 16-6 and 8 for illustrated ground locations.

Except KX, KS, KY models:



KX, KS, KY models:





- D: Engine wire harness
- E: Right engine compartment wire harness
- G: Main wire harness
- H: Radio condenser ground wire (On Carbureted engine, this wire is included in the distributor primary lead)



L.H. Drive:

NOTE: See page 16-9 for illustrated ground locations.



[E]: Right engine compartment wire harness
[I]: A/C wire harness



(cont'd)

Ground Distribution

Circuit Identification (cont'd)

R.H. Drive:


NOTE: See page 16-9 for illustrated ground locations.






NOTE: See page 16-10 for illustrated ground locations.


L.H. Drive:



L.H. Drive:



R.H. Drive:



[J]: Left engine compartment wire harness


(cont'd)

Ground Distribution

Circuit Identification (cont'd)

L.H. Drive:

NOTE: See pages 16-11 and 12 for illustrated ground locations.




G: Main wire harness
K: Driver's door wire harness
L: Passenger's door wire harness
M: Dashboard wire harness



R.H. Drive:

NOTE: See pages 16-11 and 12 for illustrated ground locations.




(cont'd)

Ground Distribution

Circuit Identification (cont'd)

NOTE: See pages 16-12 and 15 for illustrated ground locations.



M: Dashboard wire harness
N: Rear wire harness
O: Defogger ground wire