


Stereo Sound System

Component Location Index



Description

For the stereo radio/cassette player description, please see the owner's manual.

The automatic antenna mast is controlled entirely by the radio ON/OFF switch. It will extend fully any time the radio switch is on and the ignition switch is on. When the radio is shut off, it retracts fully. The power antenna motor has a built-in relay together with a limit switch for this function.