

Body Dimensional Drawings

Upper Body Measuring Dimensions

Engine Compartment

2.5TL 6-2

3.2TL 6-3

Passenger Compartment 6-4

Under Body Measuring Dimensions

2.5TL 6-5

3.2TL 6-6

Opening Repair Chart 6-7

Frame Repair Chart

2.5TL 6-8

3.2TL 6-10