


Construction



NOTE: Be sure to use epoxy-based putty and primer surfacer to make any repairs on paint coats or zinc-plated sheet metal (see page 3-3).

No.	Part Name	Zinc-plated		No.	Part Name	Zinc-plated	
		Both Sides	One Side			Both Sides	One Side
①	Hood	○		⑱	Front Pillar Lower Stiffener	○	
②	Front Fender	○		⑳	Inside Sill	○	
③	Front Door Panel/Door Skin	○		㉑	Roof Side Rail		
④	Rear Door Panel/Door Skin	○		㉒	Roof Panel		
⑤	Trunk Lid	○		㉓	Center Pillar Stiffener		
⑥	Front Side Bulkhead	○		㉔	Center Pillar Inner		
⑦	Bulkhead Upper Frame	○		㉕	Rear Inner Panel	○	
⑧	Front Lower Cross Member	○		㉖	Rear Wheelhouse	○	
⑨	Wheelhouse Upper Member	○		㉗	Parcel Shelf		
⑩	Front Wheelhouse	○		㉘	Front Floor	○	
⑪	Damper Housing	○		㉙	Middle Floor Cross Member	○	
⑫	Front Side Frame	○		⑳	Rear Floor	○	
⑬	Front Side Outrigger/Front Side Extension	○		㉑	Rear Panel	○	
⑭	Dashboard Lower	○		㉒	Side Sill Extension	○	
⑮	Dashboard Upper	○		㉓	Rear Frame Extension	○	
⑯	Outer Panel	○		㉔	Rear Frame	○	
⑰	Front Pillar Inner Lower	○		㉕	Rear Floor Cross Member	○	
⑱	Front Pillar Inner Upper			㉖	Honeycomb Floors (2.5TL)		