


Preparation of Work


Measurement (Excluding small damage)

Whenever possible, make judgements and conclusions based on measurement. Measure the wheel alignment (see page 1-2) so as to prevent any future trouble like unsymmetrical wear of the tires or catching of the steering wheel.

If there are any deviations, use a tram tracking gauge and measure parts of the body.



If there is any twisting to the body, measure using a frame centering gauge.



When measuring body dimensions, use a universal tram gauge.

