

General Information

| | | | |
|--|------|---------------------------|------|
| Construction | 4-2 | *Windshield Lower | |
| Front Fender | | Description | 4-30 |
| Replacement | 4-3 | Mass Production Body | |
| Front Bulkhead | | Welding Diagram | 4-30 |
| Description | 4-4 | Replacement | 4-30 |
| Mass Production Body | | Side Sill/Outer Panel | |
| Welding Diagram | 4-4 | Description | 4-32 |
| Replacement | 4-5 | Mass Production Body | |
| *Front Wheelhouse/Damper Housing | | Welding Diagram | 4-32 |
| Description | 4-8 | Replacement | 4-33 |
| Mass Production Body | | Roof Panel | |
| Welding Diagram | 4-8 | Description | 4-36 |
| Replacement | 4-10 | Mass Production Body | |
| *Front Side Frame | | Welding Diagram | 4-36 |
| Description | 4-14 | Replacement | 4-37 |
| Mass Production Body | | Rear Side Outer Panel | |
| Welding Diagram | 4-14 | Description | 4-40 |
| Replacement | 4-16 | Mass Production Body | |
| *Front Side Outrigger/Front Side Extension | | Welding Diagram | 4-40 |
| Description | 4-21 | Replacement | 4-41 |
| Mass Production Body | | Rear Panel | |
| Welding Diagram | 4-21 | Description | 4-45 |
| Replacement | 4-23 | Mass Production Body | |
| *Front Pillar (Outer Panel) | | Welding Diagram | 4-45 |
| Description | 4-26 | Replacement | 4-46 |
| Mass Production Body | | Rear Floor | |
| Welding Diagram | 4-26 | Description | 4-49 |
| Replacement | 4-27 | Mass Production Body | |
| | | Welding Diagram | 4-49 |
| | | Replacement | 4-50 |
| | | Rear Floor Cross Member | |
| | | Description | 4-55 |
| | | Mass Production Body | |
| | | Welding Diagram | 4-55 |
| | | Replacement | 4-56 |
| | | *Honeycomb Floors (2.5TL) | |
| | | Replacement | 4-58 |

Items marked with an asterisk (*) include SRS components; special caution is required when servicing.

Body Welding Symbols