

# Rust-preventive Treatments


## Undercoating Diagram

 indicates PVC coating areas.

### NOTE:







- Coating thickness: 0.5 mm (0.02 in) MIN.
- Follow the above instructions for paint repair or refinishing.
- Avoid coating on the front and rear suspensions, and exhaust system mount area.
- Items marked with an asterisk (\*) on the important control areas.  
Coating thickness 1 mm (0.04 in).

Unit: mm (in)



**VIEW V**






FUEL CAP ADAPTOR  
Do not apply to the mounting nut area.



**SECTION CC**

**SECTION AA**

**SECTION GG**



**SECTION DD**

**SECTION EE**

**VIEW M**

**SECTION HH**