

Front Pillar (Outer Panel)

Description

The front pillar is connected to the roof, windshield, the door hinges, and side sills and is a highly important support. Connection of the front pillar determines the position of the windshield and front door. Align the front fender, door, and windshield while the front pillar is loosely mounted, and check the clearances and level differences.

Mass Production Body Welding Diagram

