

Rear Floor Cross Member

Description

The rear floor cross member position is critical for rear wheel alignment. During replacement, check the position of the rear beam and rear damper base and position the rear floor cross member properly.

Weld securely following the welder manufacturer's instructions to maintain rigidity. Use of the positioning jig is recommended.

Mass Production Body Welding Diagram

