

# Cross Section of Body and Sealants


NOTE: Seal the following areas to prevent air leaks, water leaks and rust.

► : Sealing locations

Spot Sealer: 3M #08892 (Internal)  
: 3M #08893 (External)

Use materials above or equivalents.

## 2.5TL: <EngineCompartment>



## <Front Wheelhouse>

